





Back View



Back View



4K HDBase-T with USB Kit - EHB-150-W

1723 W. 4th Street Tempe Arizona 85281

P: 800.638.6104 | F: 480.966.6728 | E: sales@covid.com | www.covid.com



Table or Contents

roduction
atures
ckage
ecifications
eration Controls & Functions
scriptions
plication Example
arranty
fety Information

Introduction



This HDBaseT transmitter can extend HDMI over a single CAT5e/6/6A cable. It can be transmitted up to 132ft/40m for 4K2K@50/60Hz (4:2:0) and 4K30Hz (4:4:4), or 1080P up to 230ft/70m. This product offers support for one independent analog audio, one way RS232 signal pass-through with HDMI and USB unidirectional signal transmission. This powerful product combo is perfect for classrooms and meeting room applications.

Features

- HDMI 1.4b 10.2Gbps, HDCP 2.2 compliant
- Up to 4K2K@50/60Hz(4:2:0), 4K2K@30Hz(4:4:4), 1080p@120Hz
- HDBaseT[™] over a single CAT5e/6/6A cable up to 230ft/70m distance at 1080p or 132/40m distance at 4K30.
- One HDMI input, 1 Gang US Decora Wall Plate
- One independent analog audio signal transmission from transmitter to receiver
- Supports HDR, CEC pass through
- Supports USB 2.0

See the description 1 on page 6

• 24V POC (Power Over Cable) function is supported, either TX or RX is powered by 24V1A power supply, the another does not need power supply from the DC jack. POC Power consumption is less than 10W.

See the description 2 on page 6

Transfer Bidirectional RS-232 control signal together with the HDMI signal.

Package Contents

- HDMI Wall Plate Transmitter 1PC
- HDBaseT Receiver 1PC
- Phoenix connector (3 pins) 1PCS
- Phoenix connector (2 pins) 1PCS
- 24V/1A power adapter 1PCS

- Cover plate 1PCS
- Rack ears 2PCS
- User Manual 1PC



Technical Specifications


Technical				
HDMI Compliance	HDMI 1.4b			
HDCP Compliance	HDCP 2.2			
Video Bandwidth	10.2Gbps			
Video Resolutions	4K2K@50/60Hz 4:2:0, 4K2K@30Hz 4:4:4 1080P@120Hz, and 1080P			
	3D@60Hz			
Color Space	RGB, YCbCr 4:4:4, YCbCr 4:2:2			
Color Depth	8-bit, 10-bit, 12-bit			
HDMI Audio Formats	LPCM, Dolby Digital/Plus/EX, Dolby True HD, DTS, DTS-EX,DTS-96/24, DTS			
	High Res, DTS-HD Master Audio, DSD			
Analog Audio Formats	LPCM 2CH, LPCM 5.1, Dolby Digital 2/5.1CH, DTS			
	2/5.1CH			
ESD Protection	Human body model - +/- 8kV (air-gap discharge) & +/-4kV (contact discharge)			

Connections			
Transmitter	Inputs:	1x HDMI Type A [19-pin female]	1x RS-232 [3-pin phoenix]
		1x AUDIO IN [3.5mm earphone]	1x DC 24V/GND [2-pin phoenix]
		1x USB [USB-B]	Outputs: 1x HDBaseT OUT [RJ45]
Receiver	Inputs:	1x HDBaseT IN [RJ45]	Outputs: 1x HDMI Type A [19-pin female]
		1x DC 24V (locking power)	1x AUDIO OUT [3.5mm earphone]
			1x RS-232 [3-pin phoenix]
			2x USB [USB-A]

Mechanical			
Housing	Metal Enclosure		
Color	TX: White-Front Panel, Black-Rear Case, RX: Black		
Dimensions	TX: 103.5mm [W] x 46mm [D] x 30mm [H]		
	RX: 140mm [W] x 75mm [D] x 23mm [H]		
Weight	TX: 163g, RX: 200g		
Power Supply	Input: AC100 - 240V 50/60Hz, Output: DC 24V/1A		
	(US/EU standards, CE/FCC/UL certified)		
Power Consumption	9W (Max)		
Operation Temperature	32 - 104 °F / 0 - 40 °C		
Storage Temperature	-4 - 140°F / -20 - 60°C		
Relative Humidity	20 - 90% RH (no condensation)		




Operation Controls and Functions



Front Panel Trans

Transmitter

- 1. **HDMI IN:** Connect to HDMI source devices such as Blu-ray or PS4 player.
- 2. **ACTIVE:** Green LED input signal indicator. When the HDMI port has a signal input, the light is on. Otherwise, the light is off.
- 3. AUDIO IN: Analog audio input port.
- 4. **USB:** Connect to PC or other USB host.





Back Panel Transmitter

Transmitter

- 1. **RS-232:** Use the phoenix jack for connect PC or control system to transmit RS-232 commands.
- 2. **HDBaseT OUT:** HDBaseT output port. Connect HDBaseT receiver with an UTP cable.
- 3. DC 24V: Use the phoenix jack to connect power supply. (Reserved power supply).







Receiver Panel


Transmitter

- 1. **Power LED:** When the power supply is normal, the indicator LED is on.
- 2. LINK LED: LINK LED indicator light.
- 3. **HDCP LED:** HDCP status indicator light.
- 4. **ACT LED:** When the device is working, the LED light is on.
- 5. **F/W:** Firmware update use.
- 6. HDBaseT IN: HDBaseT input port. Connect HDBaseT transmitter with an UTP cable.
- 7. **HDMI OUT:** HDMI output port. Connect to the display device such as TV or projector.
- 8. **USB:** Connect to USB device such as USB mouse or keyboard.
- 9. AUDIO OUT: Analog audio input port.
- 10. **RS-232:** Use the phoenix jack to connect PC or control system to transmit RS-232 commands.
- 11. DC 24V: Connect 24V/1A adapter to AC wall outlet for power supply.




Description 1


POC (Power Over Cable) Application Example



Description 2


Bidirectional RS-232 Control Application Example







Application Example





Warranty

Parts and labor warranty time is three year and from the date of original shipment. This warranty shall be void if a serial number has been removed from the product.

Upon determination of a legitimate defect covered by this warranty and at COVID's sole discretion, user should bear the transport cost during the warranty.

If product is out of warranty then repair charge is required. Out of warranty repairs will only be made after cost has been approved by Customers and proper financial arrangements are made. Customer must cover round trip shipment expenses.

Safety Information



To reduce the risk of electric shock, do not expose this product to rain or moisture.



Do not modify the wall plug. Doing so will void the warranty and safety features.



If the wall plug does not fit into your local power socket, hire an electrician to replace your obsolete socket.



This equipment should be installed near the socket outlet and the device should be easily accessible in the case it requires disconnection.